

## 2. Important Safety Instructions

1. Read and keep these instructions. Heed all warnings and follow all Instructions
2. Clean only with dry cloth
3. Do not block any ventilation inlet or outlet and maintain good ventilation
4. Do not use near any heat sources such as radiators, heat registers, stoves, or other apparatus
5. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit into your outlet consult an electrician for replacement of the obsolete outlet.
6. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from Blawesome.
7. Only use attachment/accessories specified by the manufacturer.
8. Unplug Blawesome during lightning storms or when unused for long periods of time
9. Refer all servicing to qualified service personnel. Servicing is required when the device was damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus.
10. Power Sources: This product should be connected to a power supply only of the type described in these operating instructions.
11. Water and moisture: This product should be kept away from direct contact with liquids.
12. Protective earthing terminal: The apparatus should be connected to a mains socket outlet with a protecting earthing connection.

**CAUTION:** TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE ANY COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL ONLY.

**WARNING:** WE RECOMMEND TO NOT CONNECT HEATING (SWITCH POSITION "I") IF AIR TEMPERATURE IS ABOVE 85°F / 30°C

**WARNING:** To reduce the risk of fire or electrical shock, do not expose this appliance to rain, water or other liquids. Electrical equipment should NEVER be kept or stored in damp environments.

**CAUTION** (for U.S.A. & Canada) TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted.



**Correct Disposal of This Product:** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer.



**General Note on the Declaration of Conformity:** We hereby declare that this device is in accordance with the essential requirements of the European Directive 1999/5/EC.

# BLAWESOME

THEWETSUITDRYER.com

Manual and Warranty documentation Version 1.0

# BLAWESOME

THEWETSUITDRYER.com

1. User Guide (1)

2. Important Safety Instructions (2)

3. Warranty Information (3-4)